

Instructions



drive in the trunk the tool's blade using exclusively a **rubber** or **plastic** hammer.



the tool driven in the trunk



grasp "Trepbor" how shown in the picture, rotate and extract it



using the "extratcing needle" push lightly the microcore on the top ...



...and then the microcore goes in the slit of the tool



the microcore is ready to be kept in an appropriate storage container.